

Measuring instructions – Conservatory blinds

Please note: Our conservatory blinds are only suitable for UPVC windows with a rubber gasket holding the glass in place. When testing if your window is compatible please use a butter knife to perform the test. The thickness of the knife will mimic the thickness of the bracket we use with this style.

Checking Your Window Is Suitable:



To ensure that your window is suitable, slide a butter knife into your rubber gasket and push it as far as it will go. To help the knife ease in, you can use washing up liquid or furniture polish.



Mark the distance the blade travels under the gasket.



Measure this distance and if it is **at least** 10mm, your window can accommodate our conservatory blinds.



Measuring Your Window:



To order your blinds, measure across your window between each rubber gasket/seal, at 3 different points (top, middle, bottom).

Note down the shortest distance to the nearest millimetre and use this as your width measurement.

Repeat the process to find the height of the window by measuring across 3 points (left, middle, right) between the rubber gasket/seals.

Note down the shortest distance to the nearest millimetre and use this as your drop measurement.

Decide on the colour and style that you prefer and place your order.

It really is that simple!